


REPAIR PARTS

ROTARY LAWN MOWER -- MODEL NO. 4CA



REPAIR PARTS

ROTARY LAWN MOWER -- MODEL NO. 4CA

KEY PART NO. NO.

DESCRIPTION

1	63601	Locknut 1/4-20
2	86902	Control Bar
3	132001	Rope Guide
4	169709X479	Upper Handle
5	169708X479	Lower Handle
6	63601	Locknut 1/4-20
7	131959	Handle Bolt 5/16-18
11	156569	Engine Zone Control Cable
12	750097	Hex Washer Head Screw #10-24 x 1/2
13	86899X004	Up-Stop Bracket
16	136376	Handle Knob
19	51793	Hairpin Cotter
21	165858	Rear Deflector
22	66426	Wire Tie
23	160831	Discharge Guard
27	160832	Torsion Spring
30	160833	Hinge Rod
33	63124	Locknut 5/16-18
34	170373X479	Wheel Bracket Support (Left)
35	170374X479	Wheel Bracket Support (Right)
36	160835X007	Wheel Bracket Adjuster
39	168360X004	Selector Spring
40	87877	Selector Knob
41	167131X004	Axle Arm Assembly (RR)

KEY PART NO. NO.

DESCRIPTION

43	19112222	Washer
44	160828	Shoulder Bolt
45	701401	Wheel Assembly (Rear)
46	83923	Locknut 1/16-18
47	146247	Wheel Assembly (Front)
48	57143	Washer
50	77400	Hubcap
51	74760514	Hex Head Bolt 5/16-18
52	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
55	107339X	Danger Decal
59	165187	Lawn Mower Housing (Incl. Key Nos. 55)
61	851514	Blade Adapter
62	141114	22" Blade
63	851074	Hardened Washer
64	850263	Helical Lockwasher 3/8
65	851084	Screw Hex Head 3/8-24 x 1-3/8 (Grd. 8)
67	-----	Engine - Briggs & Stratton 12H802
70	167130X004	Order parts from engine manufacturer
72	167132X004	Axle Arm Assm. (LR)
73	167133X004	Axle Arm Assm. (LF)
74	751153	Axle Arm Assm. (RF)
75	160830	Nut
76	161622	Plate. Mulcher
77	74760412	Clip. Closeout
--	162300	Screw
--	172782	Warning Decal (Not shown)
--	171897	Operator's Manual (English)
--		Replacement Parts Manual

Available accessories not included with mower:

--	GCK3300	Grass Catcher
----	---------	---------------